


Linde Material Handling

*Linde*



# Guidelines for the return condition of your Linde hire equipment





## 1. Overhead Guard (if applicable)

### Acceptable

- Undamaged and operational
- Complete

### Unacceptable

- OHG structure damaged or bent
- Protective screens broken or scored
- Operator's compartment incomplete (compared to delivery condition)

## 2. Chassis

### Acceptable

- No Impact damage on chassis sides
- Protective grill fitted
- Minor paint damage is acceptable

### Unacceptable

- Bent or damaged chassis panels
- Damaged chassis cover panels
- Major sticker or paint residue

## 3. Wheel / Tyres and Axles

### Acceptable

- Tyres / Wheels and axles free from external damage
- Free from shrink wrap and other binding products

### Unacceptable

- Sheared securing bolts (wheels or axle)
- Shrink warp bear damage
- Bent wheel rims
- Cuts in tyres

## 4. Truck lighting and working lamps

### Acceptable

- Complete as when supplied
- Undamaged
- Blown bulbs are acceptable

### Unacceptable

- Missing or damaged lights, beacons
- Cracks, fractures or deep score marks
- Bent mountings or light protection frames
- Missing key or damaged keyswitch

## 5. Mast (if applicable)

### Acceptable

- Hydraulic hoses complete and undamaged
- Lifting chains complete and undamaged
- Lifting cylinder complete and undamaged
- Fork carriage straight and undamaged

### Unacceptable

- Damaged mast profile
- Broken mast or carriage rollers
- Lift cylinder damaged or bent
- Damaged hydraulic hoses
- Bent or damaged fork carriage/sideshift
- Damaged load back-rest

## 6. Operator's compartment (including seat)

### Acceptable

- Compartment complete and undamaged
- Steering wheel and spinner knob complete
- Floor mats undamaged and present
- Seat fully functional and tear free
- Tiller/handlebar complete and damage free

### Unacceptable

- Broken / damaged levers or switches
- Missing covers
- Deep scratches, holes in the dashboard
- Floor plate damaged or missing

## 7. Power systems

### Acceptable

- Sufficient battery charge for loading
- Cables and connectors undamaged
- No major damage to electric system and or electronic components

### Unacceptable

- Battery and/or charger missing or damaged
- Damaged battery cables